


INSTRUCTIONS




29996


29996 Component list

P/N	Part description	Q'	TY	Unit	Remarks
T-01	Base	1		Pc	Part 4 adjust screw
T-02	Bottom box	1		Pc	
T-03	Down side frame	2		Pcs	
T-04	Pole	1		Pc	
T-05	Side hooks-4	8		Pcs	
T-06	Middle hooks-5	10		Pcs	
T-07	Middle hooks-6	1		pc	
T-08	Up side frame	2		pcs	
T-09	Top hook-8	1		Pc	
T-10	Name-plate	1		pc	
T-11	Screws M8*35	33		pcs	
T-12	Screws M8*20	4		Pcs	
T-13	Ring M12	1		pc	
T-14	Capac M12	1		pc	


28896 Component list




IPe




8Pca




IPe




10Pca




2Pca



IPe




IPe




2Pca

29996 Component list




1Pc

T-09




1Pc

T-10




33Pcs

T-11




4Pcs

T-12



1Pc

T-13



1Pc

T-14